

*The use of an isolated power supply is recommended for powering all Walrus Audio Pedals.

Daisy chain power supplies are not recommended.

– ∞ MOMENTARY FEATURES ∞

BYPASS SWITCH - Holding down the Bypass switch, when the pedal is engaged, allows you to set the secondary LFO rate and control the amount of drift added to the LFO by turning the Rate and Depth knobs.

TAP SWITCH - Hold down the tap switch to ramp to the secondary LFO rate. If the secondary LFO rate is faster than the current rate, the pedal will ramp up to it. If the secondary rate is set slower, it will ramp down.

— ∞ TAP / EXPRESSION JACK ∞


The Tap/EXP jack can serve as either an external tap input or an expression pedal input. Before using this jack, be sure to set the internal dip switches to the position that corresponds to the intended use.

If connecting an external tap, make sure it is a normally open source with a latch time of less than 250ms.

To assign an expression pedal, enter assignment mode by holding down both the Bypass and Tap switches until the bypass LED blinks rapidly. While continuing to hold the switches, turn either the Depth knob, Rate knob, or both to assign them to be controlled by the expression pedal. To clear an assignment, enter the assignment mode and exit the mode by releasing both stomp switched without turning any knobs. Make sure to use a TRS cable to connect the expression pedal, and that the pedal you are using is configured to send the control signal on the tip conductor of the cable.



Oot questions or need a repair or want to mail us some cookies? Email help@walrusaudio.com
All our pedals come with a limited lifetime warranty, walrusaudio.com/pages/warranty-and-repair for more info.



Julianna STEREO CHORUS/VIBRAT

STEREO CHORUS/VIBRATO

– ∞ CONTROLS ∞ -

RATE - The Rate knob allows you to control the speed of the main LFO.

SECONDARY FUNCTION: MOMENTARY LFO RATE - The Rate knob also allows you to set the momentary LFO rate. While the pedal is engaged, hold down the bypass switch and turn the Rate knob. The Bypass LED will blink at the momentary LFO rate and will turn solid once you release the Bypass switch, storing your momentary LFO rate setting. See Momentary Features section to learn more.

DEPTH - The Depth knob controls the strength of the chorus and vibrato effect by setting the amplitude of the LFO.

SEGONDARY FUNCTION: DRIFT - The secondary function of the Depth knob sets the amount of 'Drift' applied to the LFO. The Drift feature on the Julianna gently speeds up and slows down the current rate of the LFO based on the amount of Drift applied. It's like a little robot is inside your pedal moving the Rate knob up and down. Lower settings offer a small amount of Drift while higher settings are more dramatic. To introduce Drift, hold down the Bypass switch, with the pedal engaged and turn the Depth knob to the desired setting. To turn Drift off, follow the same procedure and set the Depth knob to zero.

LAG – The Lag knob lets you set the center delay time that the LFO modulates around. From smooth, tight modulation at lower settings, to noisy and nauseating detune at maximum.

D-G-V BLEND - The DCV knob sets the ratio of dry to wet signal through the mono channel of the Julianna. Traditional mono chorus sounds can be heard with the knob set around noon. Pitch vibrato is found in the full clockwise position. The ground in between offers unique blends of chorus and vibrato not commonly found on other chorus pedals.

When both outputs are connected, set the DCV knob to full counterclockwise to send your dry signal to the mono output and vibrato signal to the stereo output for a traditional stereo chorus sound. Explore other variations by turning the DCV knob up slightly to add some vibrato signal to the dry output changing the stereo image.

DIV SWITCH - The Div switch lets you select a quarter note, quarter note triplet, or eighth note multiplier to scale a tapped in tempo.

NOTE: the div switch only operates on a tapped tempo, not the Rate knob.

SHAPE SWITCH - The Shape toggle lets you select a sine, triangle, or random LFO wave to modulate the pitch of your signal. There are no rules here. Sine is traditionally used for vibrato tones and triangle for chorus, but feel free to change it up! The random wave is a true random LFO and is awesome for creating unpredictable pitch vibrato effects. The random wave combined with the drift effect makes for seasick unpredictability. Take some Dramamine and give it a try.

BYPASS LED - Illuminated when the effect is engaged and blinks the secondary LFO rate when holding down the Bypass switch when the pedal is engaged. Note the Julianna remembers its last known bypass state. If you turn your pedalboard off with the Julianna engaged, the next time you power it up, it will automatically power up engaged. This is great for players who use a bypass looper to avoid having to turn the pedal on manually each time they power on their pedalboard.

 \overline{TAP} LED – The Tap LED pulses at the rate of the LFO set by the Rate knob or the rate of a tapped in tempo.