


# IMPORTANT!

Adjust the Mic Presence Control  
for each guitar with this tool




**MIC PRESENCE CONTROL**



Detailed installation instructions are available  
for authorized dealers at [lrbaggs.com/support](http://lrbaggs.com/support)

---

Register Lyric at [lrbaggs.com/register](http://lrbaggs.com/register)



### **A. MIC PRESENCE CONTROL**

**NOTE:** Setting this control correctly is vital to optimizing the LYRIC's sound and performance.

Play through a P.A. or good acoustic amplifier when making your adjustments with the tool provided on the front of this card. This control is highly responsive, so make subtle adjustments.

Your amplified tone should be well balanced and true to the acoustic sound and feel of the guitar. If it lacks clarity and top-end, increase the mic's presence by turning the control clockwise. Back it off slightly if you experience excessive handling noise and/or brightness.

### **B. VOLUME CONTROL**

Roll this wheel toward the neck to increase the volume or towards the bridge to decrease the volume.