


MP3 USB record module

The file system of USB memory for USB players is FAT16 and FAT32 and these players can only decode MP3. It has 7 rank subordinate folders at most.

- A USB port: Allows the connection of any USB memory stick.
- B  PRE: Use this button to go back to the beginning of the current track or select a previous track for playing.
- C  NEXT: Use this button to skip to the next track.
- D  RPT: Use this button to repeat one track, one folder or all tracks.
Repeat All: Plays the complete medium several times, the symbol on the screen is 
Repeat: Repeats a single track several times, the symbol on the screen is 
Play in order: play all the tracks in order, the symbol on the screen is blank.
Random play: All tracks will be played back in random order, the symbol on the screen is A.
- E  PLAY / PAUSE: Use this button to start playback. Press once to start playback, twice to set the pause mode and again to resume playback.
- F REC: Press this key to enable the recording preparation state. Press REC again to start recording. Any other operations are not available in the recording state until POWER is pressed to stop recording.
- G POWER(Push & Hold): When the power switch is pressed for 2-3 seconds, the device turns on.
- H DISPLAY: All MP3 player information is monitored via this display.





©2013 DAP Audio