

electro-harmonix

EHX Volume

Congratulations on your purchase of the EHX Volume pedal. The volume pedal enables you to use your foot to expressively control the volume of your guitar, bass, keyboard, or other musical instrument leaving your hands free to play the instrument. The rugged—yet lightweight—design includes selectable input impedance making this one of the most universally compatible volume pedals available today.

- CONTROLS, I/O JACKS -

INPUT Jack – Plug a standard 1/4" instrument cable with TS plug into this jack. Connect the other end of the cable to your guitar, bass, another effects pedal, keyboard, or other instrument.

OUTPUT Jack – Plug a standard 1/4" instrument cable with TS plug into this jack. Connect the other end of the cable to your amp, other effects pedals, or another device such as a mixing console or recording interface.

HI-Z/LO-Z Button – This button allows you to select the impedance of the Volume pedal from LO-Z to HI-Z. The impedances presented for each setting are the following:

LO-Z = 25k Ω

HI-Z = 250k Ω

We recommend the HI-Z, or **in** setting, for most guitar and bass signals. The LO-Z, or **out** position, is best suited for keyboards and other electronic musical instruments as well as line level signals.

Foot Pedal – As you sweep the foot pedal from heel to toe the volume of the signal increases from minimum to maximum. The output signal is muted in the heel position.

- WARRANTY INFORMATION -

Please register online at <http://www.ehx.com/product-registration> or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term.

If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. Customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at info@ehx.com or +1-718-937-8300. USA and Canadian customers: please obtain a **Return Authorization Number** (RA#) from EHX Customer Service before returning your product. Include—with your returned unit—a written description of the problem as well as your name, address, telephone number, e-mail address, RA# and a copy of your receipt clearly showing the purchase date.

United States & Canada

EHX CUSTOMER SERVICE
ELECTRO-HARMONIX
c/o NEW SENSOR CORP.
55-01 2ND STREET
LONG ISLAND CITY, NY 11101

Tel: 718-937-8300
Email: info@ehx.com

Europe

JOHN WILLIAMS
ELECTRO-HARMONIX UK
13 CWMDONKIN TERRACE
SWANSEA SA2 0RQ
UNITED KINGDOM

Tel: +44 179 247 3258
Email: electroharmonixuk@virginmedia.com